# MEGA STORE

<GB>

## INTRODUCTION

The Mega Store is an accessory which really adds fun to your POWER PALZ™ pet; you can "purchase" various items from it for your pet. Items provided by the Mega Store can be grouped into the following categories: Food, Drink, Entertainment, Medical, Education, Health, Luxury Goods and Mystery Items. Once you enter the store, you can buy whatever you like without any limitation. Depending on the item you purchase, the personal indices of your pet will change accordingly. For example, if you buy a cake for your pet, its happiness is increased, its hunger is decreased, but its discipline is also decreased.
The Mega Store is, therefore, an outstanding little supermarket that can give you much fun and laughter and benefit you pet immensely. But watch out for those mystery purchases!!

## KEY DEFINITION

- ON/ OFF: Press ON/OFF to start the game and end the game.

## FUNCTION DEFINITION

**OPERATIONAL PROCESS OF IR PET AND MEGA STORE**

| | Power Palz™ | MEGA STORE |
|---|---|---|
| 1. | The pet is in its normal mode | Press ON/OFF to start the game and enter the waiting mode. |
| 2. | Press the IR key and wait for the feedback from the store | Call accepted and the entrance opens. The communication is successful! |
| 3. | Press ENTER to open the door, and the food menu is shown. | |
| 4. | Press SELECT key to browse through different categories: (Food) (Education) (Drinks) (Doctor) (Mystery) (Leisure) (Health) (Goods) | While making your purchases, the moving-trolley graphics will be shown. |
| 5. | Press ENTER to enter the selected menu. Press SELECT to browse through all items available in a category. Press ENTER to confirm the selection. The goods are put into the trolley. | |
| 6. | will be shown on both the Power Palz™ and Mega Store to confirm the purchase. | |
| 7. | Return to the last shopping menu. | |
| 8. | At anytime, you can leave the store by pressing ESC and enter the leaving menu; | The moving-trolley graphics are continually showed. |
| 9. | In the leaving menu, select the leaving graphics by pressing SELECT and by pressing ENTER. | Once confirmed, will be shown, and the trolley will be pushed to the cashier to pay for the goods. You will then leave the store. |
| 10. | The Power Palz™ will go back to its normal mode | The Mega Store looks forward to your next visit. |



## Products for sale

A full list of items available (grouped into different categories) is summarized below:

### • FOOD

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| cake | decrease | increase | decrease | | increase | increase |
| Ice cream | decrease | increase | decrease | | | |
| Apple | increase | | decrease | | | increase |
| Pear | increase | | decrease | | | increase |
| Banana | increase | | decrease | | | Increase |
| Pineapple | increase | | decrease | | | increase |
| Cherries | increase | | decrease | | | Increase |
| Hamburger | decrease | increase | decrease | | | Increase |
| Cookies | decrease | increase | decrease | | | Increase |
| Hot dog | decrease | increase | decrease | | | increase |
| Pizza | decrease | increase | decrease | | | increase |
| Pie | decrease | increase | decrease | | | increase |
| Strawberries | increase | | decrease | | | increase |
| Cheese | increase | | decrease | | | increase |
| Candy/Sweets | decrease | increase | decrease | | | |
| Sandwich | increase | | decrease | | | increase |
| Bone | increase | increase | decrease | | | increase |
| Leg of lamb | increase | | decrease | | | increase |
| Pancake | decrease | increase | decrease | | | |
| Shrimp | | | decrease | | | increase |
| Crab | | | decrease | | | increase |
| Fish | | | decrease | | | increase |
| Egg | increase | | decrease | | | increase |
| Turkey | | | decrease | | | increase |
| Soup | | | decrease | | | increase |



| | | | | | | |
|---|---|---|---|---|---|---|
| Bread | | | decrease | | | increase |
| Peach | increase | | decrease | | | increase |
| Orange | increase | | decrease | | | increase |
| Lemon | increase | | decrease | | | increase |
| Coconut | increase | | decrease | | | increase |
| Tomato | increase | | decrease | | | increase |
| Potato | increase | | decrease | | | increase |
| Carrot | increase | | decrease | | | increase |
| Mushroom | increase | | decrease | | | increase |
| Onion | increase | | decrease | | | increase |
| Popcorn | decrease | increase | decrease | | | increase |
| Crisps | decrease | increase | decrease | | | increase |
| Sausage | | | decrease | | | increase |
| Steak | | | decrease | | | increase |
| Spaghetti | | | decrease | | | increase |
| Fries | decrease | | decrease | | | increase |
| Donut | | | decrease | | | increase |

### • DRINKS

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Water | increase | | | | | |
| Orange Juice | increase | increase | | | | |
| Tea | increase | | | | | |
| Milk | increase | | | | | increase |
| Cola | decrease | | | | | |

### • LEISURE

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Walking | increase | increase | increase | | increase | decrease |
| Running | increase | increase | increase | | increase | decrease |

| | | | | | | |
|---|---|---|---|---|---|---|
| Dancing | increase | increase | increase | decrease | increase | decrease |
| Surfing | increase | increase | increase | decrease | increase | decrease |
| BBQ | increase | increase | increase | decrease | increase | decrease |
| Radio | | increase | | decrease | | |
| Cycling | increase | increase | increase | decrease | increase | decrease |
| Gardening | increase | increase | increase | | increase | decrease |
| Cinema | | increase | | decrease | | |
| Tennis | increase | increase | increase | decrease | increase | decrease |
| Fishing | increase | increase | increase | decrease | increase | decrease |
| Ping Pong | increase | increase | increase | decrease | increase | decrease |
| Sky Diving | increase | increase | increase | decrease | increase | decrease |
| Climbing | increase | increase | increase | decrease | increase | decrease |
| Kite Flying | increase | increase | increase | decrease | | decrease |
| Skiing | increase | increase | increase | decrease | increase | decrease |
| Camping | increase | increase | increase | decrease | | decrease |
| Karaoke | | increase | | decrease | | |
| Soccer | increase | increase | increase | decrease | increase | decrease |
| Football | increase | increase | increase | decrease | increase | decrease |
| Golf | increase | increase | increase | decrease | increase | decrease |
| Basketball | increase | increase | increase | decrease | increase | decrease |
| Beach | increase | increase | increase | decrease | | decrease |
| Circus | increase | increase | increase | decrease | | decrease |
| Walkman | | increase | | decrease | | |
| Shopping | | increase | increase | decrease | | decrease |
| Ballooning | | increase | increase | decrease | | decrease |
| Baseball | increase | increase | increase | decrease | increase | decrease |
| Skating | increase | increase | increase | decrease | increase | decrease |
| Car Racing | increase | increase | increase | decrease | | decrease |
| Gamming | | increase | increase | decrease | increase | decrease |



## • DOCTOR

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Pills | increase | decrease | | | increase | |
| Injection | increase | decrease | | | increase | |
| Medicine | increase | decrease | | | increase | |

## • EDUCATION

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Writing | | increase | increase | increase | | decrease |
| Reading | | increase | increase | increase | | decrease |
| Teacher | | increase | increase | increase | | decrease |
| Prize | | increase | | | | |
| Computer | | increase | increase | | | decrease |

## • HEALTH

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Sauna | increase | increase | | | increase | |
| Pedicure | increase | increase | | | increase | |
| Mail order | increase | increase | | | increase | |
| Shampoo | increase | decrease | | | | |
| Haircut | increase | decrease | | | | |
| Swimming | increase | increase | increase | | increase | decrease |
| Jacuzzi | increase | increase | increase | | increase | decrease |
| Aerobics | increase | increase | increase | | increase | decrease |
| Gymnastic | increase | increase | increase | | increase | decrease |
| Shower | increase | decrease | increase | | | decrease |

## • GOODS

| | Health | Happiness | Hunger | Discipline | Strength | Energy |
|---|---|---|---|---|---|---|
| Clothes | | increase | | decrease | | |
| Shoes | | increase | | decrease | | |
| Car | | increase | | decrease | | |
| TV | | increase | | decrease | | |



| | | | | | | |
|---|---|---|---|---|---|---|
| Hi Fi | | increase | | decrease | | |
| Motorbike | | increase | | decrease | | |
| Plane | | increase | | decrease | | |
| Skis | | increase | | decrease | | |
| Mobile Phone | | increase | | decrease | | |
| CDs | | increase | | decrease | | |

## • MYSTERY

| | | | |
|---|---|---|---|
| Kiss | Mystery | Party | Fight |
| Holiday | Mystery | Mystery | Mystery |
| Mystery | Press ups | Skateboard | Banana skin |
| Passport | Crown | Pet Human | Scorpion |
| Spider | Clock | Laptop | Guitar |

## RESET

If the game malfunctions, press the RESET key with a sharp pointed device, such as a ballpoint pen. This will reset the game to the demonstration mode.

## INSERTING THE BATTERY

To insert the battery, remove the battery compartment cover at the back of the game by unscrewing the cover. Insert 2 x AG13 cell batteries as shown in the figure.

## ⚠CAUTION

- Batteries should always be replaced by adult.
- Do not give tools to children to open the battery door.
- This product is not suitable for children under 36 months due to small parts which may present a choking hazard.
- Batteries are to be inserted with the correct polarity.
- Only batteries of the same or equivalent type as recommended are to be used.
- The game unit may contain small parts
- Replace batteries when you notice the screen is dimmer than normal.
- Different type of batteries or new and used batteries are not mixed.
- Non rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the game unit before being charged.
- Rechargeable batteries are only to be changed under adult supervision.
- Exhausted batteries are to be removed from the game unit.
- The supply terminals are not to be short-circuited.

© 2004 Gamze Ltd.
GAMZE™ is a registered trademark of Gamze Ltd.
All Rights Reserved
Made and Printed in China

BC016A-02C-MA1